



# SCF830-D-AS

## DIESEL ENGINE DRIVEN CONFIGURABLE-PROGRAMMABLE FIRE PUMP CONTROL PANEL



## INSTALLATION AND OPERATION INSTRUCTIONS

IO-SCF830-D-AS 01-EN-Rev.0  
02-2019



## 1. SCOPE OF THE DOCUMENT

The purpose of this technical document is to provide the necessary elements to facilitate the correct installation and basic operation of the SCF830-D-AS control panel. The user needs to obtain more information regarding the design, justification of components, operation etc. Please contact us at the following address [svecorp@svecorp.com](mailto:svecorp@svecorp.com)

## 2. MAIN FEATURES

N°	STANDARDS AND TECHNICAL REGULATIONS					
01	Compliance with standards and technical regulations	AS 2941 regulation 2013				
02		AS/NZS 3000:2007 Standard				
03		EN 61439-1 Low-voltage switchgear				
N°	ELECTRICAL FEATURES AND BATTERIES					
04	Incoming line voltage and frequency	From 85V to 265 VAC 50-60Hz depending on model				
05	Nominal battery voltage	12 VDC or 24 VDC depending on model				
06	Battery chargers	Models				
07		SBA12030	SBB12070	SBB12100	SBB24035	SBB24050
08	Nominal charging current	3A	7 A	10 A	3,5 A	5 A
09	Supported battery capacity (C10)	86 Ah	200 Ah	285 Ah	100 Ah	142 Ah
10	DIN power	41,4 W	96,6 W	138,0 W	96,6 W	138,0 W
11	Performance	85% nominal power				
12	Float voltage drift	< 1% from 0% to 90% of nominal current load				
13	Supported batteries (except SBA12030)	Lead-Acid open fluid		Lead-Acid VRLA (AGM or GEL)		
		NiCd-(9-18 cells)		NiCd-(10-20 cells)		
14	Charge current drift	< 5% from 50% to 99% of the float voltage				
N°	DESIGN FEATURES					
15	Enclosure	IP65 Protected from total dust ingress (NEMA 4)				
16		Impact rating: IK10 (except for display)				
17		Fireproof grade: Fire extinguishes <30s				
18	Display	Transflective: Visible under direct sunlight				
19	Wiring	Halogen free				
20		Fire resistance: RZ1 according to EN50200 (830° during 90min)				
21	Pressure sensor	1 pressure measuring device using pressure transducers 0-100bar / 4-20mA It can be used to monitor the system pressure of the pump The demand pressure to start and stop the pump are configurable (probe not supplied)				
22	Working temperatures	Recommended: -5°C to 40°C (tested up to 60°C)				
23	Electromagnetic environment	CEM-1				
N°	PUMP AND SYSTEM PROTECTIONS					
24	Total system alarms	28				
N°	PUMP START METHODS					
25	Automatic Mode	Pressure switch line: Low system pressure				
26		Manometer: system pressure				
27		Water level contact: Low priming tank level				
28		Remote start contact				



29	Emergency start	"Start Battery " and " Monitor Battery " press buttons in front panel
N°	<b>ENGINE STARTING SYSTEM</b>	
30	2 Starting solenoids	levers: 1.000 Amp independent / adjacent included
N°	<b>MEASURING INSTRUMENTS</b>	
31	Batteries	2 Voltmeters, battery voltage
32		2 Battery charge current ammeters
33	Engine	Engine cooling temperature (water)
34		Engine cooling oil temperature
35		Oil pressure
36		Fuel tank level
37	General System	Engine speed in rpm
38		1 Voltmeter: Supply voltage AC. Accuracy >1%
39		1 Manometer: System pressure (4-20mA pressure sensor required)
40		1 Flow Meter (manual flow input / pulse output / 4/ 20 mA sensor)
N°	<b>OTHER INFORMATION ON DISPLAY</b>	
41	Current Date and TIME (RTC with independent battery)	Accumulated engine working hours
42	150 latest events (pump starts, alarms, ...). 500 recorded	Pump start demand type
43	150 latest records of system pressure variation. 16.000 recorded	Active Alarms
N°	<b>OTHER FEATURES</b>	
44	Pressure switch lines' monitoring with short-circuit and open circuit alarm	Engine heating management through constant engine temperature monitoring
45	Engine crank levers connection monitoring with open circuit and short circuit alarm	Cooling system operation management
46	Breakable lid to block the selected operating mode: Auto / Crank isolate	
N°	<b>VISUAL AND AUDIBLE MONITORING SIGNALS IN FRONT PANEL</b>	
47	Operating Modes	Auto
48		Crank Isolate
49	Pump status	Pump on demand
50		Pump start with A battery/ Pump start with B battery
51		Pump running with discharge pressure
52	Batteries	Battery A / Battery B correct
53		Chargers correct
54	Alarms	Delayed alarms in service
55		General alarm
56	Buzzer	80dB
57	Other	Mains voltage correct
N°	<b>COMMUNICATIONS</b>	
58	USB connector B Device type	SAF830-D←→ PC Communication
59	USB connector A Host type	SAF830-D←→ PENDRIVE Communication
60	Ethernet Modbus Protocol/ TCP-IP	LAN (local area network) port included in all models
61		WAN (Ethernet) port included in all models
62		Point-to-point port included in all models
63	RS485 Modbus Protocol/ RTU	Optional module SCOM901 not included
64	Voltage free contacts	7 Voltage-free switched contacts: 30Vdc – 0.3A



## 2.1. LIMITED WARRANTY

Seller (SVE S.L.) warrants to the original purchaser that for the period of 1 year the products sold shall be free from defects in material and workmanship. If buyer claims that a product violates this Limited Warranty, the seller, upon notice promptly given, will either examine the product at buyer's site, or issue shipping instructions for return to the seller at buyer's expense, transportation charges prepaid. The seller's sole obligation under this Limited Warranty shall be, at its option, to repair, replace or refund the price of any product thereof which is proved to violate this Limited Warranty. In no event, whether based on contract, indemnity, warranty, tort (including negligence), strict liability or otherwise, shall the seller be liable to the buyer for special, indirect, incidental or consequential damages whatsoever including, without limitation, loss of profit or revenue. THIS LIMITED WARRANTY IS THE BUYER'S EXCLUSIVE REMEDY AND THE SELLER HEREBY EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

The foregoing shall constitute the sole remedy of the buyer and the sole liability of the seller. This Limited Warranty shall not apply to any product or component thereof which has been repaired or altered by anyone other than the seller's authorized personnel in any manner so as, in the seller's sole judgment, to affect its serviceability, or to any product that has been subject to alteration, accident, misuse, abuse, neglect or normal wear. This Limited Warranty shall not apply to products which have been assembled or installed or used in a manner contrary to the seller's printed instructions, or due to failure to follow the seller's printed instructions for operation and maintenance. Any technical assistance provided by the seller's personnel or representatives in system design is construed to be a proposal and not a recommendation. The responsibility for determining feasibility rests with the user-operator and should be subject to test. Only the terms expressed in this Limited Warranty shall apply and no distributor, corporation or individual is authorized to amend, modify or extend this Limited Warranty in any way on resale.

## 2.2. CE DECLARATION OF CONFORMITY

This document refers to SCF830-D-AS diesel fire pump control panel models.

SCF830-D-AS fire pump control panels serve to automate the management of fire protection systems in accordance to the following standards and technical rules:

Standard:	AS 2941 regulation 2013
Standard:	AS/NZS 3000:2007 Standard
Standard:	EN 61439-1 Low-voltage switchgear

The mounting instructions and the description of qualities and operation refer only to the standard SCF830-D-AS fire pump control panel models. the different variants that may be developed in response to a particular requirement for a specific installation or maintenance operation are not mentioned in this document.

This product must be installed and handled by personnel with adequate training (in accordance with EN-50-110-1)

### Declaration of CE Compliance

SVE S.L. hereby declares that the SCF830-D-AS diesel fire pump control panels conform to the following directives:

- Electromagnetic compatibility, Directive CE: 2014/30/UE
- Low voltage, Directive 22014/35/UE
- Machinery Directive 2006/42/CEE
- AS/NZS 3000:2007 Standard Wiring rules

**Specific regulations applied: EN 61000-6-2, EN 61000-6-3, 61439-1, 61439-2, 60204-1.**

01/06/2018

Alvaro Cristóbal Otxandio

Gerente de SVE S.L.



Alvaro Cristóbal Otxandio  
Gerente de SVE S.L.

Avda. Gipuzkoa nº6

20500 Arrasate-Mondragón

España



### 3. SCF830-D-AS CONTROL PANEL TERMINALS

All the electrical connections must comply with the local and national codes and regulations. The control wires should be 1.5 mm<sup>2</sup> cables. The wires used to connect to the mains or power lines should be 6 mm<sup>2</sup> cable.

#### 3.1. SCF830-D-AS CONTROL PANEL TERMINAL BLOCK

	DENOMINATION	DESCRIPTION			
S1-T1	POWER AC LINE (<270 V AC)	AC power input			
S1-T2	POWER AC NEUTRAL (<270 V AC)	AC power input			
N°	DENOMINATION	TYPE	SIGNAL/CUR	VOLTAGE	LENGTH
1	O-FUEL SOLENOID / VALVE	Output: Relay	< 25 A	8-35Vcc	< 3m
2	I-COMMON BATTERIES (-)	Input: Supply	Power	(-)Vbat.	< 3m
2	I-COMMON BATTERIES (-)	Input: Supply	Power	(-)Vbat.	< 3m
3	O-CRANKING-START	Output; Relay	<10 A	8-35Vcc	< 3m
3	O-CRANKING-START	Output; Relay	<10A	8-35Vcc	< 3m
4	I-BATTERY-START (+)	Input: Supply	Power	8-35Vcc	< 3m
5	I-BATTERY-MONITOR (+)	Input: Supply	Power	8-35Vcc	< 3m
6	O-CRANKING-MONITOR	Output: Relay	<10A	8-35Vcc	< 3m
6	O-CRANKING-MONITOR	Output: Relay	<10A	8-35Vcc	< 3m
N°	DENOMINATION	TYPE	SIGNAL/CUR	VOLTAGE	LENGTH
7	O-ENGINE ALTERNATOR EXCITER	Output: Transistor	Max. 1 A.	8-35Vcc	< 3m
8-10	NO USE - DO NOT CONNECT				
N°	DENOMINATION	TYPE	SIGNAL/POWER	VOLTAGE	LENGTH
11-12	NO USE - DO NOT CONNECT				
13	O-PICKUP (+)	Output	Signal <100mA	8-35 V DC	< 3m
14	I-PICKUP/W (rpm)	Input	Signal	8-35 V DC	< 3m
15	PICKUP SHIELD-GND	GND-Reference			
N°	DENOMINATION	TYPE	SIGNAL/CUR	VOLTAGE	LENGTH
16	I- SYSTEM PRESSURE SWITCH	Input	Signal	(-)Vbat.	< 3m
17	O-REF. COMMON (-)	Output Reference			
18	I-REMOTE STOP	Input	Signal	(-)Vbat.	< 3m
19	O-REF. COMMON (-)	Output Reference			
20	I-REMOTE START	Input	Signal	(-)Vbat.	< 3m
21	O-REF. COMMON (-)	Output Reference			
22	I-PUMP DISCHARGE PRESSURE OK	Input	Signal	(-)Vbat.	< 3m
23	O-REF. COMMON (-)	Output Reference			
24	I HIGH ENGINE WATER TEMPERATURE CONTACT	Input	Signal	(-)Vbat.	< 3m
25	O-REF. COMMON (-)	Output Reference			
N°	DENOMINATION	TYPE	SIGNAL/CUR	VOLTAGE	LENGTH
26	I-LOW OIL PRESSURE CONTACT		Signal	(-)Vbat.	< 3m
27	O-REF. COMMON (-)	Output Reference			
28	I-LOW FUEL LEVEL CONTACT		Signal	(-)Vbat.	< 3m
29	O-REF. COMMON (-)	Output Reference			
30	I-CRANK MOTOR VOLTAGE (+)		Signal	8-35Vcc	< 3m




N°	DENOMINATION					
31-45	NO USE - DO NOT CONNECT					
N°	DENOMINATION		TYPE	VALUE	LENGTH	
46	I-ENGINE WATER TEMPERATURE SENSOR		Analog input	Variable resistance	< 3m	
47	NO USE - DO NOT CONNECT					
48	I- OIL PRESSURE SENSOR		Analog input	Variable resistance	< 3m	
49	NO USE - DO NOT CONNECT					
50	I-FUEL TANK LEVEL SENSOR		Analog input	Variable resistance	< 3m	
51	NO USE - DO NOT CONNECT					
52	I-ENGINE OIL TEMPERATURE SENSOR		Analog input	Variable resistance	< 3m	
53	NO USE - DO NOT CONNECT					
54	I-SYSTEM PRESSURE SENSOR		Analog input	4-20mA current	< 3m	
55	O- SYSTEM PRESSURE SENSOR SUPPLY		4-20mA current	12v	< 3m	
56	I-WATER FLOW SENSOR		Analog input	4-20mA current	< 3m	
57	O-WATER FLOW SENSOR SUPPLY		4-20mA current	12v	< 3m	
N°	DENOMINATION		TYPE	CURRENT	VOLTAGE	LENGTH
58	O-ENGINE HEATER LINE		Relay-Output	< 10 A	< 270 V AC	< 3m
59	NEUTRAL		Output	< 10 A	< 270 V AC	< 3m
60	NEUTRAL		Input	< 10 A	< 270 V AC	< 1m
61	O-ENGINE HEATER LINE		Relay-input	< 10 A	< 270 V AC	< 1m
	VOLT FREE CONTACTS					
N°	DENOMINATION		TYPE	CURRENT	VOLTAGE	
62	NC	POWER FAIL	Output: Relay	< 0,5 A	< 30 VDC	
63	COM					
64	NO					
65	NC	PUMP RUNNING WITH PRESSURE	Output: Relay	< 0,5 A	< 30 VDC	
66	COM					
67	NO					
68	NC	PUMP RUNNING WITCH PRESSURE	Output: Relay	< 0,5 A	< 30 VDC	
69	COM					
70	NO					
71	NC	FAILED TO START / DISCHARGE PRESSURE FAIL	Output: Relay	< 0,5 A	< 30 VDC	
72	COM					
73	NO					
74	NC	NOT IN AUTO MODE	Output: Relay	< 0,5 A	< 30 VDC	
75	COM					
76	NO					
77	NC	GROUPED ALARMS / CONTROL FAIL	Output: Relay	< 0,5 A	< 30 VDC	
78	COM					
79	NO					
80	NC	GROUPED ALARMS / CONTROL FAIL	Output: Relay	< 0,5 A	< 30 VDC	
81	COM					
82	NO					



### 3.1.1. RPM SENSORS (PICK-UP)

SCF830-D-AS diesel control panels accepts three types of speed sensors. The necessary connections to use any of the pick-up sensors are shown below:








### 3.1.2. INTERNAL AND EXTERNAL WIRING SCHEMATIC

N° SCF830-D-AS SCHEMATIC



Sheet <b>1</b>	Dossier Producto SCF830-D
Date <b>2019/02/20</b>	File Name EsquemaSCF830-D-AS.dwg

Title <b>WIRING DIAGRAM SCF830-D-AS</b>
--

Scale <b>1:1</b>	 www.svecorp.com
---------------------	---------------------






### 3.1.3. SHORT CIRCUIT AND OPEN CIRCUIT DETECTION IN PRESSURE SWITCHES

SCF830-D-AS control panel offers a valuable safety information on the status (correct / short circuit / open circuit) of the SYSTEM PRESSURE SWITCH (Contact), these pressure switches are key elements since they send the signal to start the pump whenever there is a demand in the system.

Two resistors need to be connected to the pressure switch or pressure switches according to the diagrams below:







The schematic is identical for one or two pressure switches, either in parallel (closed contact with low pressure) or series (open contact with low pressure).

If these resistors are connected to the pressure switches the SCF830-D-AS control panel will correctly detect the performance of the switches even though **C-1.15** parameter is configured as **C-1.15** SYSTEM PRESSURE SWITCH OPEN / SHORT CIRCUIT no detection of SC (short circuit) and OC (Open circuit).

### 3.1.4. PRESSURE SENSOR CONNECTION

SCF830-D-AS control panel can read the information provided by 4-20mA pressure sensors.



Below the wiring schematic for connecting the pressure sensors to the terminals of the SCF830-D-AS fire pump control panel.

N° PRESSURE SENSOR WIRING			
01			
02	SYSTEM PRESSURE	Terminals	<b>54</b> I-SYSTEM PRESSURE SENSOR <b>55</b> O-SYSTEM PRESSURE SENSOR SUPPLY
		Configuration parameters	<b>C-2.5</b> ENABLE SYSTEM PRESSURE SENSOR <b>C-2.6</b> END OF SCALE PRESSURE SENSOR

### 3.1.5. FLOW METER CONNECTION

SCF830-D-AS control panel can read the information provided by a 4-20mA flow meter, or a water meter with pulse outputs, SCF830-D-AS control panel will convert the pulses into a fluid flow value.

Below the wiring schematic for connecting the flow meter to the terminals of the SCF830-D control panel.

N° FLOW METER WIRING			
01	WATER COUNTER/PULSE		
02	FLOW METER 4-20 mA		Terminals
			<b>56</b> I-WATER FLOW SENSOR <b>57</b> O-WATER FLOW SENSOR SUPPLY
		Configuration parameters	<b>C-2.7</b> ENABLE FLOW METER <b>C-2.8</b> FLOW SENSOR SCALE



## 4. PRE-START UP AND START UP OPERATION

### 4.1. SAFETY PRECAUTIONS



SCF830-D-AS control panel is designed to protect buildings, goods, and people but it could represent a risk to the person handling the CONTROL PANEL since it is connected to AC mains supply.

COMPLETELY READ AND UNDERSTAND THE MATERIAL PRESENTED IN THIS DOCUMENT BEFORE ATTEMPTING INSTALLATION, OPERATION, OR APPLICATION OF THE EQUIPMENT. IN ADDITION, ONLY QUALIFIED PERSONS SHOULD BE PERMITTED TO PERFORM ANY WORK ASSOCIATED WITH THIS EQUIPMENT. ANY WIRING INSTRUCTIONS PRESENTED IN THIS DOCUMENT MUST BE FOLLOWED PRECISELY. FAILURE TO DO SO COULD CAUSE PERMANENT EQUIPMENT DAMAGE.

### 4.2. ELECTRICAL CONNECTIONS

All the electrical connections must follow the local and national electrical codes.

SCF830-D-AS control panel has an IP65 (NEMA-4) type enclosure but always has to be protected from any water source. Before installing the control panel check the marking and verify that the characteristics, electrical rating, battery type, frequency, and so forth are appropriate for the system.

Inspect all the electrical connection and make sure there are no loose wires or any damaged components before energizing it.

All control panels come with an installation manual inside the enclosure. Check the wiring schematic section of the manual to properly connect the it to the AC power source and to the diesel pump motor.

Make sure to have the appropriate tools during the installation to make the necessary holes in the grand plate for the different connections.

### 4.3. SCF830-D-AS CONTROL PANEL START AND SHUT DOWN

#### 4.3.1. SCF830-D-AS CONTROL PANEL START UP

SCF830-D-AS control panel is powered by the pump engine start batteries, that are connected to the SBA or SBB battery chargers, depending on the model, inside the SCF830-D-AS control panel. To turn the SCF830-D-AS control panel on the following steps must be followed:

Nº	TURNING ON THE SCF830-D-AS CONTROL PANEL
01	Make sure S1 isolator located in the front panel is in OFF position
02	connect the control panel to the ac power line: 230 V AC
03	Activate Q1, Q2 y Q3 circuit breakers located in the interior of the control panel
04	Close the door and turn the S1 isolator to the ON position

#### 4.3.2. SCF830-D-AS CONTROL PANEL SHUT DOWN

Whenever the main power line is expected to be down for a large period of time it is recommended to disconnect SCF830-D-AS control panel using the Q1 isolator located in the interior of the control panel to avoid using any power from the batteries to energize the control panel.





### 4.4. CONFIGURABLE PARAMETERS VERIFICATION

SCF830-D-AS control panels are configured in our facilities considering the needs of the majority of the systems, but some parameters need to be configured for specific needs.

Make sure the control panel has been configured correctly for the system it is controlling. To know more about how to configure the control panel go to section 14 CONFIGURATION MENU.



## 4.5. PUMP INSPECTION INSTRUCTIONS

N°	PUMP INSPECTION INSTRUCTIONS		
01	Follow manufacturer's instructions for prior verification of the diesel pump		
02	Verify that pump suction and discharge valves are 100% opened		
03	Press and test that the diesel the engine starts with buttons		
04	Verify that the flow and discharge pressure of the pump follow the pump curve provided by the manufacturer		
05	 Press <b>STOP</b> to stop the pump	Keep the SCF830-D-AS in  making sure there are no active pump start demands.	



## 4.6. SIGNAL INSPECTION INSTRUCTIONS

Make sure the general elements of the installation are working properly as well as their connections to the SCF830-D-AS control panel. Verify also that the all communications are working properly as well as the informational management:

N°		SIGNAL INSPECTION INSTRUCTIONS	
01	Verify the mode selector is working properly	<div>AUTO</div>	<div>CRANK ISOLATE</div>
02	Press <div>AUTO</div>	Verify system pressure sensors are working properly and make sure SCF830-D-AS acts accordingly whenever there is a system pressure variation.	
03	Simulate different system alarms and make sure the SCF830-D-AS control panel acts accordingly.		

## 5. OPERATION

### 5.1. AUTO MODE (Automatic)

N°				
1	Verify 	mode has been selected		
2	START	SCF830-D-AS receives a system demand to start the pump.		
3	STOP	 Contact switch	18 I-REMOTE STOP 19 O-REF. COMMON (-)	SCF830-D-AS control panel does not detect any demand to start the pump. It is necessary to press the button when the blue light is on. Activated when this contact is closed for a minimum time of 2s



## 5.2. CRANK ISOLATE

N°				
1	Verify that		mode has been selected	
2	START		Starting the pump is avoided in this mode. Prevents the starter from being energized during maintenance	
3	STOP		SCF830-D-AS does not detect any demand to start the pump. It is necessary to press the button when the blue light is on.	
	Contact switch		18 I-REMOTE STOP	Activated when this contact is closed for a minimum time of 2s
			19 O-REF. COMMON (-)	

## 5.3. EMERGENCY START

N°		
1	Totally independent of the electronic control and the selected operating mode	
2	START BATTERY	Activate the start solenoid (Lever) corresponding to the Start battery
3	MONITOR BATTERY	Activate the start solenoid (Lever) corresponding to the Monitor battery

## 5.4. PUMP START DEMAND

SCF830-D-AS control panels will recognize the existence of a pump run system demand in the following scenarios:

N°	FIRE PUMP START DEMAND			
1	System pressure switch	Pressure switch	16 I: SYSTEM PRESSURE SWITCH 17 O-REF. COMMON (-)	<ul style="list-style-type: none"> <li>Configurable delayed start <b>C-1.10</b> PUMP START DELAY</li> <li>Configurable pressure switch (NO/NC) <b>C-1.14</b> SYSTEM PRESSURE SWITCH</li> </ul>
2	Remote start	Contact switch	20 I-REMOTE START 21 O-REF. COMMON (-)	Demand is activated when this contact is closed for a minimum time of 2s
3	Remote stop	Contact switch	18 I-REMOTE STOP 19 O-REF. COMMON (-)	Demand triggered by remote start is disabled when this contact is closed for a minimum time of 2s
4	System pressure sensor		Terminals 55 O- SYSTEM PRESSURE SENSOR SUPPLY 54 I-SYSTEM PRESSURE SENSOR	Activated when the system pressure is below the configured pressure value <b>C-1.17</b> DEMAND PRESSURE and it deactivates whenever the system pressure reaches the configured value <b>C-1.18</b> END DEMAND PRESSURE

## 6. ALARMS

One of the SCF830-D-AS control panel basic functions is to monitor and protect the diesel engine fire pump and its water supply. This task is achieved by permanently monitoring the electrical, mechanical and hydraulic variables, and by taking the necessary actions against any given alarm.



## 6.1. ALARM DETECTION

Any alarm detection will trigger the following:


N°	ACTIONS		
1	No alarm will stop the pump		
2	Description and display of the alarm in the screen		
3	<b>ALARM</b>		lit up
4	Alarm buzzer activation		
5	Voltage free contact output actuation:	Terminals	
		80	NC
		81	COM
		82	NO
		77	NC
		78	COM
		79	NO

## 6.2. ALARM RESET

To reset and remove from the screen all non-active alarms the following steps must be followed.

N°	ALARM RESET	
1	Silence buzzer pressing	button
2	Check the cause for the alarm and solve the issue to deactivate the alarm	
3	Delete non active alarms from the display by pressing	

## 6.3. LIST OF ALARMS

N°	TEXT ON DISPLAY	DESCRIPTION	ACTION	RELATED CONFIG.	
AL-01	MAINS FAILURE	SCF830-D-AS detects that the AC mains supply is out of range on voltage or frequency.	Remote signal	<b>C-3.2:</b> MAINS MIN VOLT. <b>C-3.3:</b> MAINS MAX VOLT. <b>C-1.11:</b> MAINS VOLT ALARM DELAY	
		Terminals	<b>65</b> NC		MAINS FAILURE (65-66 connected)
			<b>66</b> COM		
			<b>67</b> NO		
This alarm will auto-reset					
AL-02	Engine OVER SPEED	SCF830-D-AS measures an engine rotational speed equal or larger than 120% of the RATED SPEED.	SCF830-D-AS orders the stop of the pump		
		 has been pressed			
		This alarm will auto-reset			
AL-03	LOW OIL PRESSURE	Active whenever SCF830-D-AS receives signal through input:		<b>C-1.12</b> DELAYED ALARMS SURVEYANCE	
		Terminals	<b>26</b> I-LOW OIL PRESSURE CONTACT		
			<b>27</b> O-REF. COMMON (-)		



AL-04	Engine HIGH WATER TEMPERATURE	Active whenever SCF830-D-AS receives signal through input:			C-1.12 DELAYED ALARMS SURVEYANCE
		Terminals	24	I HIGH WATER TEMPERATURE CONTACT	
			25	O-REF. COMMON (-)	
This alarm is only active whenever the engine starts, when the led light “Delayed alarms in service” is lit					
AL-05	LOW FUEL LEVEL	Active whenever SCF830-D-AS receives signal through input:			C-1.21: MINIMUM FUEL LEVEL ALARM
		Terminals	28	I-LOW FUEL LEVEL CONTACT	
			29	O-REF. COMMON (-)	
		Or if the fuel level is being monitored by the SCF830-D-AS CONTROL PANEL through input:			
		Terminal	50	I-FUEL TANK LEVEL SENSOR	
And the measured value drops below the configured value. This alarm will auto-reset whenever the fuel level is back to normal.					
N°	TEXT ON DISPLAY	DESCRIPTION			
AL-06	LOW BATTERY START VOLTAGE	SCF830-D-AS measures battery voltage every 5 min. Alarm is triggered if SCF830-D-AS measures that battery START voltage is below 12V o 24V (depending on the battery nominal voltage) for three consecutive measurements. This alarm will auto-reset whenever the battery voltage value is back to normal.			
AL-07	LOW BATTERY MONITOR VOLTAGE	SCF830-D-AS measures battery voltage every 5 min. Alarm is triggered if SCF830-D-AS measures that battery START voltage is below 12V o 24V (depending on the battery nominal voltage) for three consecutive measurements. This alarm will auto-reset whenever the battery voltage value is back to normal.			
AL-08	START BATTERY CHARGER FAULT	SCF830-D-AS does not receive the correct status for START battery charger signal (negative) This alarm will auto-reset whenever the conditions are back to normal.			
AL-09	MONITOR BATTERY CHARGER FAULT	SCF830-D-AS does not receive the correct status for MONITOR battery charger signal (negative) This alarm will auto-reset whenever the conditions are back to normal.			
AL-10	HEATER PROTECTION TRIPPED	SCF830-D-AS detects that the circuit breaker Q2 that protects the engine heating resistor is open.			
N°	TEXT ON DISPLAY	DESCRIPTION			RELATED CONFIG
AL-11	CRANK ENGINE VOLTAGE FAIL	SCF830-D-AS does not receive any signal from the engine cranking motor (Bendix) the moment the SCF830-D-AS sends the engine start signal.			C-1.26 BENDIX MONITORING
		Terminal	30	I-BENDIX VOLTAGE (+)	
N°	TEXT ON DISPLAY	DESCRIPTION	ACTION		RELATED CONFIG.
AL-12	FAILED TO START	In AUTO mode the SCF830-D-AS has gone through all the engine CRANK ATTEMPTS without successfully starting the engine.	Remote signal:		C-1.4: NUMBER OF CRANK ATTEMPS C-1.6 CRANKING TIME C-1.7 START REST TIME
			Terminals	71	
72	COM				
73	NO				
N°	TEXT ON DISPLAY	DESCRIPTION			RELATED CONFIG.
AL-13	LOW DISCHARGE PRESSURE	SCF830-D-AS does not measure a major pump discharge pressure even though the engine is running.			C-1.12 DELAYED ALARMS SURVEYANCE
		Terminals	22	I-PUMP DISCHARGE PRESSURE OK	
23	O-REF. COMMON (-)				
AL-14 / AL-15					NO USED
AL-16	SPEED SIGNAL FAULT	SCF830-D-AS does not detect any Pick-Up signal or the engine rotational speed is less than 25% of the engine RATED SPEED. There is 10 second time lapse from the moment the engine starts to the moment the SCF830-D-AS triggers the alarm.			C-1.2 NUMBER OF TEETH C-1.3 RATED SPEED





AL-17	PRESSURE SWITCH SHORT-CIRCUIT	SCF830-D-AS detects that the pressure switch line is in short-circuit				C-1.15 OPEN-SHORT CIRCUIT PRESSURE SWITCH	
		Terminals	16	I: SYSTEM PRESSURE SWITCH			
			17	O-REF. COMMON (-)			
		Active only when C-1.15 is configured					
AL-18	PRESSURE SWITCH OPEN-CIRCUIT	SCF830-D-AS detects that the pressure switch line is in open-circuit				C-1.15 OPEN-SHORT CIRCUIT PRESSURE SWITCH	
		Terminals	16	I: SYSTEM PRESSURE SWITCH			
			17	O-REF. COMMON (-)			
		Active only when C-1.15 is configure					
N°	TEXT ON DISPLAY	DESCRIPTION	ACTION			RELATED CONFIG.	
AL-19	MAINS FREQUENCY FAIL	SCF830-D-AS detects that mains frequency value is more than 10% over or under the alarm set point	Remote signal:			C-3.1: NOMINAL MAINS FREQUENCY	
			Terminals	65	NC		MAINS FAILURE (65-66 connected)
				66	COM		
				67	NO		
N°	TEXT ON DISPLAY	DESCRIPTION	RELATED CONFIG.				
AL-20	COMMUNICATION	SCF830-D-AS detects that there is no communication between front panel electronic baseplate and the baseplate located in the interior of the SCF830-D-AS.					
AL-21 / AL-22 / AL-23 / AL-24 / AL-25 / AL-26 / AL-27 / AL-28 / AL-29						NO USED	
N°	TEXT ON DISPLAY	DESCRIPTION					
AL-30	CRANKING COILS (LEVERS) FAULT	SCF830-D-AS detects an issue in the wire connecting the SCF830-D-AS to the engine cranking coils (levers). Open circuit or short circuit					
AL-31	LOW COOLANT TEMPERATURE	Active whenever SCF830-D-AS receives signal through input:					
		Terminals	32	I LOW WATER TEMPERATURE CONTACT			
			33	O-REF. COMMON (-)			
AL-32	DC VOLTAGE FAIL	SCF830-D-AS detects a voltage for START and MONITOR batteries lower than 5 V DC for at least 3 consecutive readouts, with 5 minutes time lapse between readouts.					
AL-33	HIGH VOLTAGE START BATTERY	SCF830-D-AS detects a voltage for START Battery to be 25% higher than its nominal voltage for three consecutive readouts. (i.e. 15V for 12V batteries)					
AL-34	HIGH VOLTAGE MONITOR BATTERY	SCF830-D-AS detects a voltage for MONITOR Battery B to be 25% higher than its nominal voltage for three consecutive readouts. (i.e. 15V for 12V batteries)					
AL-35	START BATTERY DEFECTIVE	SCF830-D-AS detects battery A voltage to be below 8V or 16V (12/24V nominal) for 0.5 seconds.					
AL-36	MONITOR BATTERY DEFECTIVE	SCF830-D-AS detects battery A voltage to be below 8V or 16V (12/24V nominal) for 0.5 seconds.					
AL-37	WATER PRESSURE SENSOR FAULT	The pressure sensor offers an output beyond its nominal range of 4-20mA					

## 7. EVENTS LOG

SCF830-D-AS control panels store the most relevant information related to the fire pump system. This event log capability is a very important tool for the authorized people involved in the maintenance of the pump and troubleshooting the root cause for the events. The event log is displayed in two different ways or places:

- SCF830-D-AS control panel: Up to 150 events
- SSW1005 Software: Up to 500 events



## 7.1. MONITORING EVENTS ON DISPLAY

EVENTS	
OFF MODE M. PUMP	09:10 15/05/04
AL01-NORMAL POWER LOSS	08:32 15/05/04
PRIMING TANK LL ON	06:50 15/05/04
PRIMING TANK LL OFF	06:28 15/05/04
AL10-L PRIMING TANK LEVEL	06:28 15/05/04
OFF MODE M. PUMP	06:10 15/05/04

Use the press buttons and to scroll through the different screen and access the EVENT screen where 150 of the latest events can be found.

- Event description
- Date-time.

To scroll down and view more events push

To exit events screen press

## 7.2. LIST OF EVENTS

Below a list of all the events that can be registered:

N°	NAME ON DISPLAY	DESCRIPTION
E-1	AL-12 FAIL TO STAR	Engine start failure alarm
E-2	AL-07 LOW MONITOR BATTERY VOLTAGE	Battery B low voltage alarm
E-3	AL-13 LOW DISCHARGE PRESSURE	Pump discharge pressure failure alarm
E-4	AL-02 OVERSPEED	Engine over speed alarm
E-5	AL-05 LOW FUEL LEVEL	Low fuel level alarm
E-6	AL-03 LOW OIL PRESSURE	Low oil pressure alarm
E-9	AL-08 START CHARGER FAULT	Start battery charger alarm
E-10	A-L09 MONITOR CHARGER FAULT	Monitor battery charger alarm
E-11	AL-10 HEATER PROTECTION TRIPPED	Open heater resistor circuit breaker alarm
E-12	AL-04 HIGH ENGINE WATER TEMPERATURE	Coolant high temperature alarm
E-13	AL-01 MAINS FAILURE	Mains power supply failure alarm
E-16	AL-16 SPEED SIGNAL FAULT	Pickup signal failure alarm
E-17	AL-06 LOW START BATTERY VOLTAGE	Low start battery voltage alarm
E-19	AUTO MODE	CONTROL PANEL is in AUTO MODE
E-20	CRANK ISOLATE MODE	CONTROL PANEL is in MAN MODE
E-21	PUMP START	Pump start/crank order
E-22	PUMP STOP	Pump stop order
E-23	REMOTE START CONTACT: ON	Remote start contact activated
E-24	REMOTE START CONTACT: OFF	Remote start contact disabled
E-25	AL-11- CRANK ENGINE VOLTAGE FAILURE	Engine cranking motor voltage failure alarm
E-40	DEMAND PRESSURE SWITCH: ON	Low system pressure read by pressure switch
E-54	DEMAND PRESSURE SWITCH: OFF	System pressure read by pressure switch back to normal
E-56	MAINS VOLTAGE OK	Mains power supply back to normal conditions
E-63	AL-33 HIGH VOLTAGE START BATTERY	Start battery high voltage alarm
E-69	START PRESS BUTTON	START button pressed in SCF830-D-AS
E-69	STOP PRESS BUTTON	STOP button pressed in SCF830-D-AS
E-80	CONFIGURED BY USB	SCF830-D-AS has been configured via USB port
E-92	AL-19 MAINS FREQUENCY FAIL	Mains frequency failure alarm
E-100	AL-17 PRESSURE SWITCH SHORT CICUIT	SYSTEM PRESSURE SWITCH in short circuit alarm
E-101	AL-18 PRESSURE SWITCH OPEN CIRCUIT	SYSTEM PRESSURE SWITCH in open circuit alarm



E-114	REMOTE START	A remote start process is initiated due to remote start
E-115	REMOTE STOP	A remote stop process is initiated due to remote stop
E-116	AL-37 WATER PRESSURE SENSOR FAULT	Water pressure sensor fault alarm
E-119	MANUALLY CONFIGURED	SCF830-D-AS has been configured manually
E-122	EVENTS ERASED	Event log has been deleted
E-124	AL-20 COMMUNICATION	Base – Control configuration failure alarm
E-134	AL-30 CRANKING LEVERS FAULT	Engine Ignition coil failure alarm
E-135	AL-34 HIGH VOLTAGE MONITOR BATTERY	Battery B high voltage alarm
E-137	AL-32 DC VOLTAGE FAIL	Battery power supply failure alarm
E-138	AL-35 BATTERY A DEFFECTIVE	Battery A defective or non-existent alarm
E-139	AL-36 BATTERY B DEFFECTIVE	Battery A defective or non-existent alarm
E-140	DEMAND SENSOR: ON	Low system pressure read by sensor
E-141	DEMAND SENSOR: OFF	Low system pressure read by sensor back to normal
E-151	PUMP RUNNING	Pump running
E-152	PUMP STOPPED	Pump stopped
E-153	CONFIGURED BY MODBUS	Configured by modbus

## 8. SYSTEM PRESSURE LOG

SCF830-D-AS control panel stores up to 16.000 pressure value data captured by the system pressure sensor **54** I-SYSTEM PRESSURE SENSOR.

The SCF830-D-AS control panel will store a new pressure data value whenever any of the following happens:

N°	PRESSURE VALUE CAPTURE
01	Engine start demand activation
02	Engine start demand deactivation
03	Change in pump status from stop to running or vice versa
05	Pressure change: the SCF830-D-AS will capture a new pressure data point if there is a big enough difference between two consecutive captured values, see <b>C-2.14</b> PRESSURE VARIATION REGISTRY
06	Every 30 min even there is no event or pressure variation

Whenever a new pressure data is registered the SCF830-D-AS control panel shows the following information:

N°	PRESSURE LOG DATA
01	Date y time: YY/MM/DD hh: mm: ss
02	Captured system pressure: XX.X bar
03	Configured pump start demand pressure at that moment: <b>C-1.17</b> DEMAND PRESSURE
04	Configured end of demand at that moment: <b>C-1.18</b> STOP PRESSURE
05	Status registers: Visible only using the SSW1005 software and downloading the information via USB.
06	Status 0: Demand status: 1: Existing pump start demand / 0: Non existing pump start demand Status 1: Pump status: 1: Pump running / 0: Pump not running

### 8.1. MONITORING SYSTEM PRESSURE LOG ON DISPLAY

Using the press button to switch between display screens and the PRESSURES screen can be selected to see the latest 150 pressure logged events



PRESSURES LOG					Latest 150 logged pressure: <ul style="list-style-type: none"> <li>○ Date-hour-minute-second</li> <li>○ Pressure value</li> <li>○ Demand activation-deactivation order.</li> </ul>
hh:mm:ss	AA/MM/DD	Pres	Start	Stop	
15/05/04 09:10:00		010.0	08.0	012.0	
15/05/04 09:20:00		010.1	08.0	012.0	
15/05/04 09:30:00		010.3	08.0	012.0	To Access more events press
15/05/04 09:40:00		010.3	08.0	012.0	
15/05/04 09:50:00		010.2	08.0	012.0	To exit the pressure event list press

## 8.2. PUMP TEST

SCF830-D-AS control panel allows to register and store on its internal memory the results of the periodical fire pump tests that are obligatory by most international fire pump installation standards and technical rules.

Up to 50 fire pump tests can be stored and for every test the SCF830-D-AS control panel can save the test results for up to 5 test points. Each of the stored fire pump tests are identified using four characters, the maintenance user-operator in charge of the fire pump test will be the one selecting these four characters as well as introducing the date and time when the test has been performed.

For every test point saved during the fire pump test the following information will be registered in the SCF830-D-AS control panel (as long as the required sensors are connected):

N°	FIRE PUMP TEST INFORMATION			
P1:	Pump discharge pressure or system pressure		T2:	Oil temperature
Q:	Flow		P:	Oil pressure
V:	Engine rotational speed			

## 8.3. PRECONDITIONS

N°	THINGS TO BE CHECKED BEFORE PERFORMING THE FIRE PUMP TEST	
01	Pump discharge pressure or system pressure	<b>54</b> I-SYSTEM PRESSURE SENSOR Parameters: <b>C-2.5</b> ENABLE SYSTEM PRESSURE SENSOR and <b>C-2.6</b> SYSTEM PRESSURE SENSOR SCALE
03	Flow	<b>56</b> I-WATER FLOW SENSOR Parameters: <b>C-2.7</b> ENABLE FLOW SENSOR y <b>C-2.8</b> FLOW SENSOR SCALE Without a flow sensor. Manual entry Parameter: <b>C-2.7</b> ENABLE FLOW SENSOR: No

## 8.4. ACCESS AND EXIT FIRE PUMP TEST MENU

To access the fire pump test screen scroll to the maintenance screen:

N°		
1	Access	<div> <div> <div>MAINTENANCE</div> <div>✓   ACCES</div> </div> <div> <div>MAINTENANCE</div> <div>&gt; Pump Test Download Info. Test In-Out</div> </div> </div>
3	Exit without saving	Press  button



## 8.5. FIRE PUMP TEST REGISTRY

Below a description on how to create new fire pump test and viewing recorded tests:

N°		
1	<div> </div> <p>Select <b>MAN</b> mode and to enable <b>START A</b>, <b>START B</b> and <b>STOP</b> push buttons</p> <div> </div>	
	<div> <b>PUMP TEST</b>            &gt; New Test            07/03/2016 09:55 S-01            02/03/2016 12:32 S-05            25/02/2016 15:10 S-01            15/01/2016 08:26 S-02         </div>	Test start and registered tests visualization
2	<div> <b>New Test...</b>            Insert Name/ID:            A AA →         </div>	To register a new fire pump test: Introduce the user-operatorname in charge for the new pump test
Register the different points (up to 5) that are part of the fire pump test:		
Using a flowmeter	<div> <b>New Test...</b>            Point #1:            p:5.3bar V:2950 rpm            Q:20.0m3/s T2:72°C            ✓ SAVE POINT            ↩ FINISH            P: 7,2 bar         </div>	<ul style="list-style-type: none"> <li>Open or close the necessary valves</li> <li>Start the fire pump</li> <li>Monitor the flow values in SCF830-D-AS display</li> <li>Press  to save the test value</li> </ul>
Inputing flow values manually using press buttons	<div> <b>New Test...</b>            Point #1:            p:5.3bar V:2950 rpm            Q:20.0m3/s T2:72°C            ▲ INCREASE FLOW            ▼ DECREASE FLOW            P: 7,2 bar         </div>	<ul style="list-style-type: none"> <li>Press  to end the test and exit the screen</li> </ul>

## 9. INPUTS AND OUTPUTS TEST

SCF830-D-AS control panel has the capability to monitor and evaluate all the information sent and received. This is a very useful tool not only during the installation of a new fire pump system but also for the periodic maintenance operation to make sure that all the mechanical and electrical signals going from and to the SCF830-D-AS control panel are working properly, and the SCF830-D-AS control panel is detecting and processing them correctly.



## 9.1. ACCESSING AND EXITING INPUT AND OUTPUT TEST SCREEN

To access the fire pump test using the maintenance screen on the display:

N°		
1	Access	<div> <div>MAINTENANCE</div> <div>✓   ACCES</div> </div> <div> <div>MAINTENANCE</div> <div>Pump Test Download Info. &gt; Test In-Out</div> </div>
3	Exit	Press  button

### 9.1.1. DIGITAL INPUTS STATUS

DIGITAL INPUTS	
<div> <div>[113] ● [125] ○ [305] ○ [04] ○</div> <div>[115] ○ [127] ● [310] ● [05] ●</div> <div>[117] ● [301] ● [311] ● [122] ○</div> <div>[119] ○ [302] ● [312] ● [27] ○</div> <div>[121] ○ [303] ○ [02] ●</div> <div>[123] ● [304] ○ [03] ○</div> </div>	Correct status (filled circle) / Disconnected (empty circle)

### 9.1.2. DIGITAL OUTPUTS STATUS

DIGITAL OUTPUTS	
<div> <div>[01] ● [19] ● [63] ○ [B] ○</div> <div>[09] ○ [20] ● [H] ● [B] ○</div> <div>[10] ○ [23] ● [G] ○ [A] ○</div> <div>[11] ● [24] ○ [F] ● ●</div> <div>[12] ● [28] ○ [E] ●</div> <div>[17] ○ [29] ● [D] ○</div> </div>	Correct status (filled circle) / Disconnected (empty circle)

## 10. COMMUNICATIONS

SCF830-D-AS control panel offers the following communication options:

N°	COMMUNICATIONS		
01	USB	SCF830-D-AS ←-----→ PC	Monitoring / Configuration via SSW1005 software
02			Bootloader: SCF830-D-AS firmware update
03		SCF830-D-AS ←-----→ PENDRIVE	Information download from SCF830-D-AS to PENDRIVE
04		PENDRIVE ←-----→ PC	Information transfer from PENDRIVE to PC
05	Ethernet MODBUS TCP/IP	SCF830-D-AS ←-----→ PC	Monitoring / Configuration via SSW1005 software Data can be monitored using customer's SCADA system




06	RS485 MODBUS / RTU	SCF830-D-AS ←-----→ PC	Monitoring / Configuration via SSW1005 software Data can be monitored using customer's SCADA system
----	-----------------------	------------------------	--

Below a more detailed description of the communication options described in the table above:

## 10.1. USB COMMUNICATION: SCF830-D-AS (HOST) – PENDRIVE / SMARTPHONE

SCF830-D-AS control panel has a Type A USB located in the front part of its PLC that allows the user-operator to download the data into a PENDRIVE. To download the data the user-operator needs to access the MAINTENANCE screen on the SCF830-D-AS control panel display.



Connect a Pendrive or Smartphone to the front USB port of the PLC SAF830-D-AS



The files that can be downloaded into a Pendrive are the following ones:

Nº	INFORMATION THAT CAN BE DOWNLOAD INTO THE PENDRIVE		
	File name	Description	Extension
01	Monitoring	Status of all the system variables at the moment the information is downloaded into the PENDRIVE	.txt
02	Configuration parameters	Configured parameter values	.txt
03	OEM configuration parameters	OEM configured parameter values	.txt
04	Events log	Up to 500 logged events	.csv





05	Fire pump test	Up to 50 fire pump tests with 5 tests for each test	.csv
06	Pressures log	Latest 16.000 pressure values logged	.csv

## 11. CONFIGURATION MENU

SCF830-D-AS control panel can be adapted to the specific needs of fire pump systems, engineering criteria, diesel fire pump manufacturer, etc....


### 11.1. FUNCTIONS

#### 11.1.1. PRECONDITIONS

Below the necessary preconditions to be able to access the configuration menu:

N°	
1	SCF830-D-AS connected to a mains power supply or a battery power supply
2	SCF830-D-A in <b>OFF</b> mode
3	Engine not running

#### 11.1.2. PUSH BUTTON FUNCTIONS



#### 11.1.3. ACCESSING AND EXISTING CONFIGURATION MENU

N°		
1	Access	Press  and  buttons at the same time for 3 seconds
2	Exit	Press  button

### 11.2. CONFIGURATION OPTIONS

The CONFIGURATION MENU screen displays the following options:

N°	TEXT ON DISPLAY	CONFIGURABLE OPTIONS
1	DATE / TIME	DAY/MONTH/YEAR HOUR: MINUTES



2	LANGUAGE	ENGLISH / ESPAÑOL / ITALIANO / FRANÇAIS / PORTUGUES
3	PARAMETERS	Access to configurable parameters
4	CALIBRATION	Access to calibration of measurements
5	DOWNLOAD INFORMATION	Access to download the data to a data storing device
6	TEST IN-OUT	Access to the screen representing the status of the input and output signals

### 11.2.1. PARAMETERS

To modify any of the parameters the user-operator will have to enter the password in the SCF830-D-AS control panel. All control panels have the same factory setting password 0000 that can be modified by the end Á, see configurable parameters **C-5.1 ACCESS PASSWORD**.

The parameters that can be modified are separated in the following groups:

Nº	INDEX		
1	C-1 Pump	5	C-5 Password
2	C-2 Sensors	6	C-6 OEM parameters (accessed only by manufacturer)
3	C-3 Power source	7	C-7 Communications
4	C-4 Batteries	8	C-8 Test

C-1 PUMP				
Nº	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-1.2	NUMBER OF TEETH	Number of teeth on the engine flywheel	1	From 1 to 250
C-1.3	RATED SPEED	Nominal engine RPM	1500	From 1000 to 5100
C-1.4	NUMBER OF CRANK ATTEMPS	Maximum number of automatic CRANK ATTEMPTS with both batteries	6	From 1 to 99
C-1.5	CRANK WITHDRAW WITH OIL PRESSURE	Engine running detection through oil pressure	No	Yes / No
C-1.6	CRANKING TIME	CRANKING TIME in seconds for each of the attempts	10	From 1 to 99
C-1.7	START REST TIME	START REST TIME between CRANK ATTEMPS in seconds	10	From 1 to 99
C-1.8	STOP TIME	Fuel supply cut off duration to achieve a complete engine stop	15	From 2 to 99
C-1.9	AUXILIARY ALTERNATOR PRIMING	Main engine alternator auxiliary priming	No	Yes
C-1.10	PUMP START DELAY	Delay in seconds between the demand order and the diesel pump start order	5	From 0 to 240
C-1.11	MAINS VOLT ALARM DELAY	Delay in seconds between the mains power supply failure detection and the activation of the alarm <b>AL-01</b> MAINS FAILURE	5	From 0 to 99
C-1.12	DELAYED ALARMS SURVEYANCE	Delay in seconds from the time the engine running is detected to the time the SCF830-D-AS starts monitoring <b>AL-03</b> LOW OIL PRESSURE and <b>AL-13</b> DISCHARGE PRESSURE FAILURE	10	From 0 to 99
C-1.13	DISCHARGE PRESSURE CONTACT	Pressure switch type for monitoring discharge pressure <b>22</b> I-PUMP PRESSURE OK	Closed with pressure OK	Closed / Opened with pressure OK
C-1.14	SYSTEM PRESSURE SWITCH	Pressure switch type for monitoring system pressure <b>16</b> I: SYSTEM PRESSURE SWITCH	Closed with pressure OK	Closed / Opened with pressure OK



C-1.15	SYSTEM PRESSURE SWITCH OPEN / SHORT CIRCUIT	SYSTEM PRESSURE SWITCH short-circuit or open-circuit failure monitoring <b>16</b> I: SYSTEM PRESSURE SWITCH	No	Yes / No
C-1.16	ENABLE DEMAND SENSOR	Allow the SCF830-D-AS to generate a pump start demand using a pressure sensor	No	Yes / No
C-1.17	DEMAND PRESSURE	When the system pressure value, using a pressure sensor, goes below this value the SCF830-D-AS will create a pump start demand.	5,0 bar	From 0 up to <b>C-1.18</b> value
C-1.18	STOP PRESSURE	When the system pressure value, using a pressure sensor, goes over this value the SCF830-D-AS will deactivate the pump start demand.	8,0 bar	From <b>C-1.17</b> up to the nominal value of the pressure sensor in place <b>C-2.6</b> SYSTEM PRESSURE SENSOR SCALE
C-1.21	MINIMUM FUEL LEVEL ALARM	When diesel tank level measured with a sensor in % goes below <b>50</b> I-FUEL TANK LEVEL SENSOR the SCF830-D-AS will activate <b>AL-05</b> LOW FUEL LEVEL	10	From 5 to 100
C-1.22	MINIMUM HEATER TEMPERATURE	When coolant temperature measured with a sensor in °C goes below <b>46</b> I-WATER TEMPERATURE SENSOR the SCF830-D-AS will activate the engine heating resistor or glow plug	40	From 20 to <b>C-1.23</b>
C-1.23	MAXIMUM HEATER TEMPERATURE	When coolant temperature measured with a sensor in °C goes over <b>46</b> I-WATER TEMPERATURE SENSOR the SCF830-D-AS will deactivate the engine heating resistor or glow plug	80	From <b>C-1.22</b> to 100
C-1.25	HEATER OUTPUT	Engine heating resistor output management	Temperature control	Temperature control/ Always active
C-1.26	AUXILIARY CRANKING ENGINE MONITORING	Monitor input <b>30</b> I-BENDIX VOLTAGE to activate alarm <b>AL-11</b> -STARTER VOLTAGE FAILURE	Yes	Yes/No

C-2	SENSORS			
N°	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-2.1	OIL PRESSURE SENSOR	Oil Pressure Sensor Borne: <b>48</b> I-OIL PRESSURE SENSOR	None	None VDO360-081-030-009/FAE14980 FAE14630 WEMA SRP10 DATCON 0250x-00 Configurable
C-2.2	COOLANT TEMPERATURE SENSOR	Coolant sensor temperature Borne: <b>46</b> I-WATER TEMPERATURE SENSOR	None	None VDO 801-004/803-004 VDO 801-001/803-001 FAE 31020 34080 WEMA SP3 DATCON VEGLIA ELCOS TTAO/402 IVECO Configurable
C-2.3	FUEL TANK LEVEL SENSOR	Diesel tank level sensor Borne <b>50</b> : I-FUEL TANK LEVEL SENSOR	None	None VDO 221-825-011 VDO 226-801-015-001 AST BIGES 310 861-T WEMA 323234 VDO 221-825-025-002 VEGLIA DATCON 0230x_xx Configurable



C-2.4	OIL TEMPERATURE SENSOR	Oil temperature sensor Borne: <b>52</b> I-OIL TEMPERATURE SENSOR	None	None VDO 801-004/803-004 VDO 801-001/803-001 FAE 31020 34080 WEMA SP3 DATCON VEGLIA ELCOS TTAO/402 IVECO Configurable
C-2.5	ENABLE SYSTEM PRESSURE SENSOR	Oil pressure sensor connected (4-20 mA)	No	Yes / No
C-2.6	SYSTEM PRESSURE SENSOR SCALE	Maximum reading for the pressure sensor in use (4-20 mA)	16.0	0 - 100 bar 0 - 1500PSI 0 - 100.0 Kg/cm <sup>2</sup> 0 - 1020 mH <sub>2</sub> O 0 - 10000kPa
C-2.7	ENABLE FLOW SENSOR	Flow meter connected (4-20mA)	No	Yes / No
C-2.8	FLOW SENSOR SCALE	Maximum reading value (m <sup>3</sup> /h) for the flow meter in use (4-20 mA)	100	1-10000 m <sup>3</sup> /h
C-2.14	PRESSURE VARIATION REGISTRY	System pressure variation in bar that triggers a new pressure registry	0.1	0.1-10 bar 1-150 PSI 0.1-10 Kg/cm <sup>2</sup> 1-150mH <sub>2</sub> O 1-250KPa
C-3	<b>MAINS POWER SUPPLY</b>			
N°	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-3.1	NOMINAL FREQUENCY	Mains power supply frequency	50HZ	50 / 60HZ
C-3.2	MINIMUM MAINS VOLTAGE	Whenever the voltage between phases drops below this value the SCF830-D-AS generates <b>AL-01</b> MAINS VOLTAGE FAILURE	180V	From 110 V AC to <b>C-3.3</b>
C-3.3	MAXIMUM MAINS VOLTAGE	Whenever the voltage between phases goes above this value the SCF830-D-AS generates <b>AL-01</b> MAINS VOLTAGE FAILURE	250V	From <b>C-3.2</b> to 300 V AC
C-4	<b>BATTERIES</b>			
N°	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-4.1	HOURS TO NEXT EQUALIZATION	Time between battery equalization in hours performed by the battery chargers	600	NO / From 10 to 990
C-4.2	BATTERY EQUALIZATION TIME	BATTERY EQUALIZATION TIME in minutes	15	From 15 to 50
C-5	<b>PASSWORD</b>			
N°	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-5.1	NEW PASSWORD	Required passcode to modify existing system parameters	0000	From 0 to 9999

C-6	OEM PARAMETERS (MANUFACTURER)			
N°	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-6.1	BATTERIES			



C-6.1.1	NUMBER OF BATTERIES	Number of engine start batteries	2	1
C-6.1.2	INTELLIGENT CHARGER	Enable intelligent charger	Yes	No
C-6.3	OUTPUTS			
C-6.3.1	CONFIGURABLE OUTPUT 1	Configurable 1 for terminal 01 O-FUEL SOLENOID / VALVE	FUEL EXCITED RUNNING	FUEL EXCITED STOP
C-7	COMMUNICATIONS			
N°	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-7.1	MODBUS CONFIGURATION	Configuration type	ETHERNET(HMI)	ETHERNET (HMI ) RS485 (SCOM)
C-7.2	RS485 ADDRESS	Address for the RS485 commucation	1	1 to 247
C-7.3	RS485 CONFIGURATION	Configuraction for RS485 communication.	9600 8N2	9600 8N2 9600 8E1 19200 8N2 19200 8E1
C-7.4	ASSIGNED IP	ASSIGNED IP	DHCP	Static IP
C-9	SYSTEM PARAMETERS			
N°	TEXT ON DISPLAY	DESCRIPTION	OPTIONS	
C-9.1	PRESSURE MAGNITUDE	pressure magnitude	Bar	Bar PSI kgf/cm2 mH2O kPa

## 11.2.2. CALIBRATION OF MEASUREMENTS

SCF830-D-AS control panel allows to calibrate the electric analog measurements so the values displayed by the SCF830-D-AS control panel match those measured by an external measuring device that the user-operator wants to use as the standard. The user-operator will need to input in the parameter list the values measured by the external device and the SCF830-D-AS control panel will automatically adjust the measurements to the given standard.

MEASUREMENT CALIBRATION		
N°	TEXT ON DISPLAY	DESCRIPTION
01	BATTERY START VOLTAGE	Battery START voltage
02	BATTERY MONITOR VOLTAGE	Battery MONITOR voltage
03	MAINS VOLTAGE	Mains power supply voltage
04	BATTERY CHARGER START CURRENT	Battery charger A current value to charge battery A
05	BATTERY CHARGER MONITOR CURRENT	Battery charger B current value to charge battery B
06	AUXILIARY ALTERNATOR AMPS	Engine auxiliary alternator amps
07	PRESSURE TRANSDUCER P.4 mA	System pressure value at 4mA
08	PRESSURE TRANSDUCER P.20 mA	System pressure value at 20mA
09	FLOW TRANSDUCER P.4 mA	Pump flow value at 4mA
10	FLOW TRANSDUCER P.20 mA	Pump flow value at 20mA



## REGISTER OF UNITARY TESTS

WIRING AND ELECTRICAL OPERATION	
	Functional revision of control elements (locks, interlocks, ..)
	Correct positioning of components (tightening torque of the fixation)
	Visual: Insulation distances and wiring leaks (> 3 mm in air and 6.5 mm leaks)
	Contact check (tightening torque, 10% random inspection)
	Check wiring gauge (see Components list / product dossier):
	Marking revision according to Marking / product dossier:
	Ref and manufacturer, serial number
	Supply voltage
	Power
	Standards: AS 2941: regulation 2013 AS/NZS 3000:2007 Standard
INSULATION (DIELECTRIC TEST)	
<ul style="list-style-type: none"> <li>- Keep the isolator switch connected (closed).</li> <li>- Stiffness test by disconnecting the 220Vac input from one of the chargers.</li> <li>- Dielectric test voltage: 1000 V AC for 1 sec Use instrument: Isolations Prüfgerät (Guth S.A.)</li> <li>- Repeat the process leaving only the other charger connected</li> </ul>	
	Between active parts (phases, neutral) and chassis (GND). There are no perforations or contours
VERIFICATION OF GROUND CONNECTION (PROTECTION CIRCUIT):	
- Electrical continuity of the ground connection (0.1 $\Omega$ max)	
	Resistance measurement from the points furthest from the ground connection to the ground connection terminal (test: 10 A, Vmax: 1 V)

REFERENCE	SCF830-D-AS					
	12030	12070	12100	24035	24050	
MODEL:	DATE					
SERIAL NO.						
RESPONSIBLE TECHNICIAN						







**SVE, S. L.**

Avda. Guipúzcoa Nº 6  
20500 Mondragón (Guipúzcoa)  
ESPAÑA  
+34 943 77 00 35

**[www.svecorp.com](http://www.svecorp.com)**