Full Set	Enter Your Code	(?)(?)(?)(?)
	Press Full	(FULL)
Part Set	Enter Your Code	(?)(?)(?)(?)
	Press Part	(PART)
Unset	Enter Your Code	(?)(?)(?)(?)
Omit Zones	Enter Your Code	(?)(?)(?)(?)
	Press Full or Part	(FULL) or (PART)
	Press Omit	(OMIT)
	Press Zone Number(s)	(?)...
	Press Prog	(PROG)
Reset	Enter Your Code	(?)(?)(?)(?)
	Press Reset	(RESET)
Chime Set	Enter Your Code	(?)(?)(?)(?)
	Press Chime	(♪)
	Press Zone Number(s)	(?)...
	Press Prog	(PROG)
Chime Unset	Enter Your Code	(?)(?)(?)(?)
	Press Chime	(♪)
	Press Reset	(RESET)
Test Sounders & Strobe	Enter Your Code	(?)(?)(?)(?)
	Enter 00	(0)(0)
	Enter 05	(0)(5)
	Press 4. 3, 2, 1 in turn	(4)(3)(2)(1)
	Press 0	(0)
	Press Reset	(RESET)
Walk Test	Enter Your Code	(?)(?)(?)(?)
	Enter 00	(0)(0)
	Enter 06	(0)(6)
	Conduct Walk Test	**Conduct Walk Test**
	Press Reset	(RESET)
Code Change	Enter Existing Code	(?)(?)(?)(?)
	Enter 00	(0)(0)
	Enter 01	(0)(1)
	Enter New Code	(?)(?)(?)(?)
	Press Prog	(PROG)
	Press Reset	(RESET)