

How is HiGrip installed?



- Initially the asphalt or concrete surface is prepared.
- It is then coated with resin and the HiGrip™ aggregate is liberally hand distributed over the binder surface to completely cover it.
- The excess that does not adhere to the resin is swept away.
- With a 2-3-hour cure time, the HiGrip™ system is quick and easy to apply, maximising resources and minimising traffic disruption.