

FITTING INSTRUCTIONS FOR MODEL HW002 - GM

THIS MODEL IS DESIGNED TO LOCK ON 4WD, CAMPERVAN AND MOTOR HOME VEHICLES

This bracket is made with a 5° outward tilt so that the mast is vertical and will not touch the roof of the vehicle.

To Fit Gutter Mount Bracket.

Loosen nut and bolt so that the aluminium channel is clear to slide over the gutter mould.

Ensure that the lock nut is wound up the thread to touch the head of the bolt.

Position channel over the gutter at an appropriate point, check that it does not interfere with the pop-top roof when it is down.

Gently screw down bolts by hand so that the bolt is touching the inside top of the gutter. Tighten with a spanner **BUT DO NOT OVERTIGHTEN**.

The locknut, which prevents the bracket working loose, can now be screwed down to the channel and locked with a spanner.

Attach antenna mast to Gutter Mount Bracket using the connection union. Check that the mast is vertical and does not touch the roof.

Should the antenna mast be tilted towards or touching the vehicle roof take the **BLACK PLASTIC STRIP** supplied and position (as shown in the diagram). Hold in place while fitting with adhesive tape.

