



Split-Fit® Columns Round & Square Reassembly Instructions

1. Use Polyurethane Structural Adhesive available from your distributor or local hardware store. Alternately you may use a 15-20 minute epoxy for reassembling column/post halves.
CAUTION: Split-Fit® COLUMNS/POSTS ARE NOT LOAD BEARING.
2. **DO NOT CUT THE WRAPPING AROUND THE Split-Fit® COLUMN/POST UNTIL YOU HAVE COMPLETED STEP #3.**
3. Measure the opening from floor to ceiling. Cut column/post ¼" shorter to ensure there is no weight resting on the finished installation of the column/post. **TIP: CUT ONLY FROM THE BOTTOM OF THE Split-Fit® COLUMN/POST TO DESIRED LENGTH USING AN ABRASIVE SAW BLADE.**
4. If using 15-20 minute epoxy, dry fit column/post in the location to be installed to ensure adequate space is available.
5. Lay a bead of polyurethane structural adhesive to all edges to be joined. If using 15-20 epoxy, mix epoxy/adhesive to manufacturer's instructions and apply to all edges to be joined. **TIP: DO NOT APPLY EPOXY OR ADHESIVE TO ALIGNMENT KEYS ON EITHER HALF.**
6. Use tape to pull halves of column/post together and wrap 4 times at several locations. The epoxy or adhesive will be squeezed out but do not remove until it is cured. **TIP: DO NOT USE CLAMPS.**
7. Do not remove any excess epoxy or adhesive until it has gelled. Once material has gelled, remove excess with a putty knife or chisel and sand until smooth and flush to column/post.
8. Bondo® can be used to smooth out the seam as necessary.
9. Use Steps 4 - 7 to assemble caps and bases, taking care to avoid epoxy or adhesive on the pins and in the receiver holes. **TIP: INSTALL THE CAP & BASE AFTER THE Split-Fit® COLUMN/POST HAS BEEN INSTALLED AND SANDING COMPLETED.**

TOOLS REQUIRED

Safety Glasses	Tape Measure
Dust Mask	Putty Knife
Gloves	C&P Split Kit
Sandpaper	Saw with Abrasive Blade

CAUTIONS:

1. **DO NOT CAULK BASE TO SUBSTRATE. THIS MAY CAUSE MOISTURE TO BE COLLECTED AND FREEZE.**
2. **ALL HOLES MUST BE PRE-DRILLED.**
3. **DO NOT PUT CONCRETE OR ANY OTHER FILLER INSIDE THE COLUMN OR POST.**
4. **INSTALL FLASHING TO PREVENT WATER FROM ENTERING AT THE TOP OF THE Split-Fit® COLUMN OR POST. THIS ONLY APPLIES IF THE TOP OF THE CAPITAL PROJECTS OUT FROM THE SOFFIT AND IS EXPOSED TO WEATHER.**

PAINTING TIPS:

1. Do not paint using dark colors with L values of 56 to 0.
2. Sand column with 100 grit sandpaper or a sanding sponge to prepare surface for a high quality latex or oil primer. Finish with the proper finish coat.

Failure to follow Installation Instructions immediately voids Lifetime Limited Warranty.

Digger Specialties, Inc. PO Box 241 Bremen, IN 46506 866-244-1533 866-244-1553 (fax)

April 2010