### GOLF IRONS UK REBUBISHMENT PAINTING KIT

# STEP-BY-STEP INSTRUCTIONS

# VIEW DEMONSTRATION VIDEO:www.golfironsuk.co.uk

#### HOUSEHOLD ITEMS REQUIRED (NOT SUPPLIED)

DUST SHEET, RAG OR OLD CLOTH TO WORK ON SMALL PLASTIC CONTAINER FOR CLEANING SOLUTION TOILET TISSUE

# **INSTRUCTION**

#### STEP 1

- PREPARE A CLEAN AREA TO WORK.
- PLACE DUST SHEET OR RAG ON A FLAT SURFACE.
- OPEN KIT AND LAY OUT CONTENTS.
- SOURCE A SMALL PLASTIC CONTAINER FOR THE CLEANING SOLUTION.
- SOURCE TOILET TISSE.

#### STEP 2

- CLEAN GOLF CLUBS THOROUGHLY WITH WARM SOAPY WATER USING AN OLD TOOTHBRUSH.
- REMOVE ANY DIRTY, GRIM AND GREASE FROM THE WHOLE CLUB HEAD.
- CLEAN SIGHT LINES/GROOVES WITH A WIRE GOLF CLUB CLEANER.
- LEAVE TO DRY THOROUGHLY. (100% DRY)

### STEP 3

- 1. APPLY PAINT TO DESIRED WORK AREA. (APPLY MINIMAL PRESSURE TO BOTTLE)
- 2. USING A FOLDED PIECE OF TOILET TISSUE, WIPE OF EXCESS.
- 3. WITH A 2<sup>nd</sup> PIECE OF FOLDED TOILET TISSUE, WET LIGHTLY OVER THE PLASTIC CONTAINER AND WIPE AWAY ANY REMAINING EXCESS. (DO NOT OVER WET SLIGHTLY MOIST IS FINE, SQUEEZE OUT IF REQUIRED)
- 4. THE WIPING ACTION NEEDS TO BE QUITE FAST PACED AND DIAGONAL TO ANY STRAIGHT LINES.
- 5. THE COTTON BUDS CAN BE UTILISED WITH THE CLEANING SOLUTION ADDED TO THE TIP FOR CLOSE CLEANING AROUND THE WORK AREA. (AGAIN NOT TO WET MOIST IS FINE, SQUEEZE OUT IF REQUIRED) DO NOT GET TOO CLOSE TO THE WORKED ON AREA.
- 6. DO NOT WORRY IF THERE IS STILL PAINT ON UNSPECIFIED AREAS.
- 7. LEAVE TO DRY THOROUGHLY OVERNIGHT (VERY IMPORTANT, BE PATIENT)
- 8. AFTER THE OVERNIGHT DRYING IS COMPLETE, TAKE THE ABRASIVE PAD AND RUB LIGHTLY OVER THE WORKED ON AREA, THIS WILL REMOVE ANY UNWANTED RESIDUE AND PAINT FROM FLAT SURFACES, LEAVING THE RECESSED AREA PAINTED.