


## illume™ Shaftless™ Solar Skylight System Installation Option 2 - Mains Power Back Up Kit

### STANDARD INSTALLATION



There may be a need to boost light output of the illume Shaftless Solar Skylight System in low light conditions or perhaps if the illume light panel is the preferred light source in the room.

Fitting a Mains Power Back Up Kit solves this problem with the installation of an AC Panel Driver and Power Module between the Control Module and Light Panel. To switch to mains power simply connect to a standard 240v AC power outlet. The system will automatically switch over from solar to mains.

### PARTS LIST:

- 1x AC Driver Module
- 1x Power Module
- 1x AC Power Lead
- 1x Instruction Sheet

### Cable Connection

1. Fit Power Module between Light Panel and Control Module.
2. Connect:
  - BLUE** to Light Panel
  - YELLOW** to Control Module
  - RED** to AC Driver secondary
3. Connect AC lead to standard 240v 10A general purpose outlet (GPO).

**Note:** GPO must be installed by a licensed electrician within 1m of illume panel.

### MAINS POWER BACK UP WIRING DIAGRAM

