

> Applicability of Mechanical Strength Tests for Biomass Pellet Characterisation

Presented by: Dr Orla Williams Co-Authors: Carol Eastwick, Donald Giddings, Sam Kingman, Peter Sage, Edward Lester




Aims: To explore how biomass pellet mechanical strength relates to milling behaviour

Objective: Determine durability, quasi-static and dynamic strength of biomass pellets and correlate results to milling energy in 3 different mills; Hardgrove Grindability Index (HGI), Ring-Roller, and Knife Mill



Wood Pellets



Sunflower

Pellets

Eucalyptus

Pellets



Miscanthus Pellets




Steam Exploded Pellets



Microwave Pellets

Pellet Durability Test

University of Nottingham



 Pellet durability tested in accordance with BS EN 15210-1:2009


•
$$D_u = \frac{m_A}{m_B} \times 100$$

 Sunflower and mixed wood pellets failed to meet standards

Correlation between Durability and Milling Energy

University of


Nottingham






University of Nottingham

UK | CHINA | MALAYSIA






- Samples measured in 3 orientations axial, diametral and flexure using Instrom Mechanical Testing Machine
- Stress and strain values obtained from Force-Extension curves
- Test gives low strain rate (1 mm/min) mechanical strength for biomass pellets



Correlation between Diametral Strain and HGI

University of


Nottingham




Correlation between Diametral Stress and Ring-Roller Mill Energy

University of

Nottingham







<1 P

University of











SHPB Slow Motion






- Impact creates strain single which is converted into voltage output
- Engineering strain is obtained from:


$$e_s(t) = 2\frac{C_b}{L_s} \int_0^t \varepsilon_R dt$$

• Engineering stress is obtained from:

$$s_s(t) = \frac{A_B}{A_s} E_b \varepsilon_T(t)$$










Correlation between Axial Young's Modulus and Ring-Roller Milling Energy





- The pellet durability correlated with HGI (provided the pellet durability was over 97.5%) and the milling energies from a knife mill and ring-roller mill
- Low durability will result in pellets that are unsuitable for transport and comminution.
- The compressive strength of the biomass pellets at low and high strain rates and in multiple orientations was obtained using quasi-static and dynamic mechanical tests.
- At low strain rates, the biomass pellets showed the highest rigidity in axial orientations under a uniformly distributed load (axial and diametral orientations), and poor rigidity when subjected to point loads (flexure test).
- Dynamic mechanical strength and rigidity were highest in the diametral orientation.



- Pellet strength was greater at high strain rates than at low strain rates.
- Orientation was an important factor in relating mechanical strength to milling energy.
- Correlations were only observed in the diametral orientation at low strain rates and in the axial orientation at high strain rates.
- Different torrefaction methods have varying impacts on pellet strength.
- Mechanical tests of biomass pellets can provide an indication of how a pellet will break down in the mill, but further work is required to enhance their accuracy for commercially produced biomass pellets.



Thank you for listening

For further information: Orla.Williams@Nottingham.ac.uk